

care instructions

HOW TO CARE FOR MARKO FABRICS:

DURALAST™*

PERENNIAL CLASSICS™

TRUFINISH™

SOFTWEAVE™

Marko recommends that you always wash your new linens before putting them into service.

Wash:

Separate colors. Machine wash with warm water at no more than 2/3 of your machine's load capacity. Wash temperature should be between 140°-160°F (60°-71°C). Use a non-ionic/solvent combination detergent recommended for synthetics or a commercial equivalent. For best care and effective soil release, a washing cycle time of 10 to 20 minutes should be sufficient.

Dry:

Use the permanent press cycle and load dryer to 1/2 capacity to ensure linens can tumble freely. Allow a cool down cycle time of at least 3-4 minutes. Remove immediately and fold.

**SoftWeave is produced with an advanced stain release technology that allows you to wash at only 120° (32°C) and use only half the detergent*

SOLANA

Wash:

Follow the same laundering instructions for above linens, except lower the water temperature to between 60°-80°F (16°-27°C).

Dry:

Use the permanent press cycle and load dryer to 1/2 capacity to ensure linens can tumble freely. Allow a cool down cycle time of at least 3-4 minutes. Remove immediately and fold.

VINYL PRODUCTS

Marko recommends that you always wipe-down your new Vinyl tablecoverings before putting them into service.

Wash:

Vinyl only needs to have the top surface wiped with a simple solution of 1 part liquid dish detergent to 10 parts warm water. Wipe off excess soap with a soft, non-abrasive damp cloth or sponge. Finish by thoroughly drying with a clean soft cloth.

Vinyl products are NOT machine-washable.

Stains are easier to remove if they are wiped-up right away. Some extremely caustic or high-fat food products may leave stains that cannot be completely removed if allowed to set.

DO NOT use any cleaning products containing ammonia, benzyl chlorides or harsh solvents and abrasive products. Many commercial window cleaners and sanitizing solutions contain ammonia or chlorine and should not be used on Vinyl.

DO NOT get Vinyl plush backing wet.

DO NOT get Table Padding foam backing wet.

DO NOT expose Vinyl products to open flames or any direct heat source. Vinyl can be permanently damaged if exposed to excessive heat.

CONSULT THE EXPERTS!

The instructions shown above are general guidelines to help you care for your Marko products. For specific formulations and instructions, consult with your chemical supplier.